

GN032-SBH | Bicycle Handlebar Mount



GN032-SBH
Bicycle Handlebar Mount

Package Contents:

(1) GN032-SBH - Bicycle handlebar mount

Compatible with:


- All Arkon dual T-tab pattern phone cradles and adapter plates
- Most Garmin 17mm ball connections. (See website for full list.)




Precaution: Arkon strongly recommends using a securing strap to provide extra protection for your device. Failure to do so may result in damage to your device. Do not operate portable devices while riding. Arkon Resources, Inc. assumes no liability for safety of bicycle rider or portable device.

Bicycle Handlebar Mounting

- Step 1. Choose a safe location on the handlebars of your bicycle in which to mount the pedestal.
- Step 2. Using a screwdriver, remove the two mounting screws (A) in order to release the ball plate and swivel head (B) so the mount can be placed around the handlebars.




- Step 3. Wrap the rubber rings (C) around the handlebar and reassemble the ball plate and swivel head (B) around the rubber rings. Secure the mount assembly by using the screwdriver to retighten the two mounting screws.



Garmin brand name and Nüvi and StreetPilot product names are trademarks or registered trademarks of Garmin International. Arkon Resources, Inc. is not affiliated with Garmin Intl.


Attach Universal Cradle to Bicycle Mount

- Step 1. Attach the universal cradle to the swivel head by firmly inserting the dual T-tabs (C) into the dual T-slots (D) on the back of the device or cradle. Adjust the angle and rotation of the head by tightening the swivel-tightening ring (E).



Attaching a Garmin Device

- Step 1. Remove the swivel ball head to reveal the 17mm ball on the ball plate. Attach your Garmin device (not included, sold separately) by firmly inserting the ball head (F) into the cavity (G) in the back of the device.



(Garmin device
not included)



Safety Precautions

Do not reposition the pedestal while cycling or driving. Arkon Resources, Inc. does not promote the adjustment of mobile devices except when the bicycle or vehicle is safely parked or stopped.

Arkon is not responsible for any damages caused to your bicycle, your device, or yourself due to the installation or use of this product.

ARKON[®]
RESOURCES INC.

The Mobile Mounting Specialists™

Consumer Hotline:

USA (800) 841-0884

INT'L (626) 254-9005

Monday - Friday 9 am - 5 pm, PST

www.arkon.com

Arcadia, CA 91006 USA

Designed in USA | Made in Taiwan

© Copyright 2010 Arkon Resources, Inc.